

REPLACEMENT PARTS GUIDE

4044M Compact Utility Tractor (OOS) (PIN: 1LV4044M**L*00001-)

ELECTRICAL



KEY
[RE183935](#)



ROTARY SWITCH
[LVA21501](#) (14 V)



WET DISCHARGE BATTERY
[TY26442B](#) (12 V, 65 AH)
[TY27797B](#) (STANDARD DUTY, 12 V, 60 AH)



LED WORK LIGHT, OOS
[AM143579](#) (12 V)



HEADLIGHT
[TA24237](#) (RH, WORK LAMP)
[TA24236](#) (LH, WORK LAMP)
[R136239](#) (BULB, 12 V)

FUEL & AIR



FILLER CAP
[AL213202](#)

CAB (IF EQUIPPED)



FRESH AIR FILTER
[MIU10010](#)
RECIRCULATION AIR FILTER
[MIU10011](#)
Service or Change every 50 hrs.

TRANSMISSION/ HYDRAULIC



TRANSMISSION/HYDRAULIC OIL
[TY22000](#) (John Deere Low Viscosity Hy-Gard™ - 47.3 L (12.5 gal))
Change after every 400 Hrs. or annually.



OIL FILTER
[RE45864](#) (TRANSMISSION)
[LVA10419](#) (HYDRAULIC)
Change after every 400 Hrs.



V - BELT
[TR131486](#) (LGTH = 1112 mm,
WIDTH = 13.4 mm, TK = 9.6 mm)



ENGINE



ENGINE OIL
[TY26669](#) (John Deere Plus-50™ II Premium)
(10W-30) (5.4 L (5.7 qt))
Change every 400 hrs/ Annually.



SPIN-ON FUEL FILTER
[MIA882963](#)
[MIU803127](#)

Change after every 400 Hrs/Annually.



AIR FILTER
[RE68048](#) (PRIMARY)
[RE68049](#) (SECONDARY)

Change every 600 hrs. or annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE
[TY24416](#)
GREASE GUN
[TY26183](#)

Change As Required.



FUEL-WATER SEPARATOR
[MIA885324](#) (FILTER KIT)
[MIU803127](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.



OIL FILTER
[M806419](#)
Change Every 400 Hrs or Annually, whichever comes first.



FILTER PAK
[TA25765](#)



DIESEL PARTICULATE FILTER
[MIU803276](#)

AXLE



TIE ROD
[LVA14951](#) (KIT)
[LVA14171](#)



FRONT AXLE OIL
[TY22035](#) (John Deere Low Viscosity Hy-Gard™)
(5.5 L (5.8 qt) - STANDARD)
(8.0 L (8.5 qt) - HEAVY DUTY)
Change every 600 hrs.