

REPLACEMENT PARTS GUIDE

5405 Tractor (Term IIIA Engine)



ENGINE



PRIMARY AIR FILTER

[SU29300](#)



SECONDARY AIR FILTER

[SU2931](#)

Change after every 250 hours or annually which ever comes first.



OIL FILTER

[RE507204](#) (FOR INDIA)

[T19044](#) (FOR EXPORT)

Replace after 100 and 250 hours, and then after every 250 hours.



PRIMARY FUEL FILTER

[RE508953](#)

FINAL FUEL FILTER

[RE508954](#)

Replace after every 500 hours.

HYDRAULIC



OIL FILTER

[RE45864](#)

Replace after every 100 hours or change every 1200 hours.

REPLACEMENT PARTS GUIDE

5405 Tractor (Term IIIA Engine)

CAPACITIES (Approximate):

Fuel Tank:

OOS..... 71 L (18.7 gal)
CAB..... 82 L (21.6 gal)

Crankcase including Filter Change: Plus-50™

..... 8.5 L (1.8 gal)

Cooling System: Cool-Gard™ II

OOS..... 12.5 L (2.7 gal)

Transmission and Hydraulic System: Hy-Gard™

PowrReverser™

12x12..... 43.5 L (11.48 gal)
24x12..... 45 L (11.88 gal)

SyncShuttle™

Dry Clutch Transmission..... 38 L (10 gal)
Wet Clutch Transmission..... 43 L (11.35 gal)

Mechanical Front Wheel Drive (MFWD) Axle Housing: MFWD Differential Housing Hy-Gard™

..... 4.5 L (1.18 gal)

Mechanical Front Wheel Drive (MFWD) Hubs (Each): Hy-Gard™

..... 0.7 L (0.21 gal)

REPLACEMENT PARTS GUIDE

5405 Tractor (Term IIIA Engine)

ENGINE



BRAKE DISK
[SJ40143](#)

1



CLUTCH DISK
[SJ34211](#) (DUAL CLUTCH)
[RE242274](#) (PTO)

2



ALTERNATOR
[SJ30896](#)

3



BATTERY
[AL205731](#)
[RE251538](#)

4



BELT DRIVE
[SU63793](#) (LGTH = 1340 mm)

5



CAB



SEAT
[SJ14106](#) (SEAT WITHOUT SEAT BELT)
[RE73192](#) (BOTTOM)
[SJ11391](#) (SEAT WITH SEAT BELT)

6

AXLE



TIE ROD
[RE217616](#) (2WD)
[RE208624](#) (TIE ROD ASSEMBLY)

7