

REPLACEMENT PARTS GUIDE


3R Final Tier 4 (FT4) Series Compact Utility Tractor - 3046R

CAB

FRESH AIR FILTER

[MIU10010](#)

Clean or replace after every 50 hours and as required.



RECIRCULATION AIR FILTER

[MIU10011](#)

Clean or replace after every 50 hours and as required.



ENGINE

FUEL FILTER

[MIU802421](#), [MIU803127](#) - 3046R

Replace after every 400 hours or annually, whichever occurs first.



OIL FILTER

[M806419](#)

Replace after every 200 hours or annually, whichever occurs first.



TRANSMISSION

TRANSMISSION OIL FILTER

[LVA13065](#)

Replace initially after 400 hours and change after every 1200 hours or 3 years.



HYDRAULIC

FUEL FILTER

[LVA12726](#) (CAB)
[LVA12678](#) (MFWD)



ENGINE

FUEL FILTER

[RE68048](#) (PRIMARY AIR FILTER)
[RE68049](#) (SECONDARY AIR FILTER)



CAPACITIES

3R Final Tier 4 (FT4) Series Compact Utility Tractor - 3046R

CAPACITIES (Approximate):

Fuel Tank:

Open Operator Station..... 51.1 L (13.5 gal)
Cab..... 44.5 L (11.8 gal)

**Cooling System:
Cool-Gard™ II**

Open Operator Station..... 5.3 L (1.4 gal)
Cab..... 7 L (1.85 gal)

**Crankcase with Filter:
Plus-50™ II**

3046R..... 5.7 L (1.51 gal)

**Transmission and Hydraulic System:
Hy-Gard™**

..... 25.7 L (6.8 gal)

**Front Axle:
HY-Gard™**

..... 4.8 L (1.27 gal)

**Transmission and Hydraulic System:
Hy-Gard™**

..... 25.7 L (6.8 gal)

**Front Axle:
HY-Gard™**

..... 4.8 L (1.27 gal)

REPLACEMENT PARTS GUIDE

3R Final Tier 4 (FT4) Series Compact Utility Tractor - 3046R

Engine



BRAKE DISK

[LVU801450](#) (FRICTION)
[LVU801448](#) (PLATE)
[M137105](#) (HAND BRAKE)



CLUTCH DISK

[LVU801450](#) (FRICTION)
[LVU801448](#) (STEEL)



BATTERY

[TY26498](#) (12 V)



ALTERNATOR
[LVA18613](#) (75 A)



FAN BELT DRIVE FAN

[LVU29376](#) (ALTERNATOR)
 (LGTH = 1122 mm)
[LVU29375](#) (HVAC SYSTEM) (TURBO)
 (LGTH = 1508 mm)
[M136137](#) (IDLERS AND PULLEYS) (60
 INCH) (MODESTIC) (LGTH = 3692 mm)



CAB



SEAT
[LVA19859](#) (CAB)

AXLE



TIE ROD
[LVA19527](#) (ASSEMBLY)
[LVA14959](#) (RH)
[LVA14960](#) (LH)



JOHN DEERE
 Genuine Parts and Service