

# FILTER OVERVIEW WITH SERVICE INTERVALS AND CAPACITIES

## 4895/4995 Series Windrowers

### CAB

**RECIRCULATION AIR FILTER**  
(4895, 4995) – [AH115836](#)

Clean after every 200 hours and change as required.



### CAB

**AIR FILTER, STANDARD**  
(4895, 4995) – [AH115833](#)

Clean after every 50 hours and replace as required.



### ENGINE

**SECONDARY AIR FILTER**  
(4895, 4995) – [AT178517](#)

Replace after each season and as required.



### ENGINE

**PRIMARY AIR FILTER**  
(4895, 4995) – [AT178516](#)

Replace after each season and as required.



### ENGINE

**FUEL FILTER (4895)** – [RE60021](#)

**FUEL FILTER (4995)** – [RE62419](#)

Replace after every 600 hours or each season, whichever comes first.

### ENGINE

**OIL FILTER (4895, 4995)** – [RE59754](#)

Replace after every 300 hours or each season, whichever comes first.

If John Deere Plus-50™ oil is used, along with a John Deere oil filter, the oil change interval may be extended by 100 hours.

(Click here for [capacity](#))



### HYDRAULIC

**HYDRAULIC FILTER**  
(4895, 4995) – [AH128449](#)

Replace after every 400 hours or each season, whichever comes first.

(Click here for [capacity](#))



**JOHN DEERE**  
Genuine Parts and Service

[http://www.deere.com/en\\_US/parts/servicessupport/filteroverviews.html](http://www.deere.com/en_US/parts/servicessupport/filteroverviews.html)

# CAPACITIES

## 4895/4995 Series Windrowers

### CAPACITIES (Approximate):

#### Fuel Tank:

4895-4995 ..... 322 L (85 gal)

#### Cooling System:

4895..... 27.8 L (7.4 gal)

#### Engine Oil with Filter:

4895..... 13.3 L (3.51 gal)

4995..... 20 L (5.28 gal)

#### Hydraulic System (Reservoir):

4895-4995 ..... 94 L (25 gal)

#### Final Drives Each:

4895-4995 ..... 1.8 L (0.47 gal)

#### Radiator:

4995..... 32.4 L (8.5 gal)

#### Overflow Tank:

4895-4995 ..... 0.95 L (0.25 gal)

#### Pump Drive Gear Case:

4995..... 3.8 L (1 gal)

#### Refrigerant:

..... 2000 g (4.5 lb)

[Return to Filter Overview](#)

