



# REPLACEMENT PARTS GUIDE


## 5ML Series - 5120ML (OOS and 1P0) Tractors (North America)


**ENGINE**

 **PRIMARY AIR FILTER**  
[SU20768](#)


 **SECONDARY AIR FILTER**  
[RE253519](#)

---

 **PRIMARY FUEL FILTER**  
[DZ115391](#)


 **FINAL FUEL FILTER**  
[DZ115390](#)

---


 **OPEN CRANKCASE VENTILATION (OCV)**  
[DZ105796](#)



**ENGINE**


 **OIL FILTER**  
[RE504836](#)

---

 **DIESEL EXHAUST FLUID (DEF)**  
[DZ114640](#)

---

**HYDRAULIC / TRANSMISSION**

 **OIL FILTER**  
[SJ11784](#)  
[RE577612 \(CHARGED\)](#)

Item	First 100 Hours	Every 500 Hours	Every 1500 Hours	Every 4500 Hours / 5 Years
Engine Oil Filter		Replace		
Primary Air Filter element			Replace	
Secondary Air Filter element			Replace	
Primary Fuel Filter		Replace		
Secondary Fuel Filter		Replace		
Hydraulic-Transmission Oil Filter	Replace	Replace	Replace	
Diesel Exhaust Fluid (DEF)				Replace



# CAPACITIES

## 5ML Series - 5120ML (OOS and 1P0) Tractors (North America)

Machine Components	Part no.	Capacities (approx.)
Fuel Tank	<a href="#">SJ25457</a>	112 L (29.5 gal)
	<a href="#">SJ29174</a> (HIGH CAPACITY)	144 L (38 gal)
DEF Tank Capacity	<a href="#">DZ114640</a>	12 L (3.2 gal)
Engine Oil (John Deere Plus-50™)	<a href="#">PY10850</a> (8.5L) <a href="#">PY10852</a> (6.5L) <a href="#">PYS10129</a> (4L)	12 L (3.2 gal)
Coolant (Cool-Gard™) (PowrReverser Transmission)	<a href="#">PY0747</a> (10L)	11.7 L (3.1 gal)
Coolant (Cool-Gard™) (PowrQuad PLUS and Powr8 Transmission)	<a href="#">PYS10130</a> (5L) <a href="#">PY0746</a> (1L)	13.8 L (3.6 gal)
Transmission And Hydraulic Axle Oil (Open Center Hydraulics)	<a href="#">PY0023</a> (20L)	39.5 L (10.4 gal)
Transmission And Hydraulic Axle Oil (Closed Center Hydraulics)	<a href="#">PY0980</a> (5L) <a href="#">PY0024</a> (1L)	47.5 L (12.5 gal)
Mechanical Front Wheel Drive (MFWD) Axle Oil (John Deere Hy-Gard™)	<a href="#">PY0980</a> (5L)	5 L (1.32 gal)
Mechanical Front Wheel Drive (MFWD) Hub		0.8 L (0.2 gal)

# REPLACEMENT PARTS GUIDE

## 5ML Series - 5120ML (OOS and 1P0) Tractors (North America)

### ENGINE



**BATTERY**  
[TY25879](#) (12 V)




**FAN BELT DRIVE**  
[SU33366](#) (LGTH = 1731 mm)



**ALTERNATOR**  
[DZ123153](#) (90 AMP)



**BRAKE DISK**  
[SJ27050](#)



**CLUTCH DISK**  
[SJ16888](#) (TRACTION)  
[SJ21851](#) (SPEED)  
[SJ20988](#) (PTO)

1

2

3

4

5



### CAB



**SEAT**  
[SJ25138](#) (ASSEMBLY)  
[SJ11561](#) (BACK)  
[SJ11560](#) (BOTTOM)

### AXLE



**TIE ROD**  
[RE271437](#) (ASSEMBLY)  
[RE271440](#) (BALL JOINT)  
[RE271441](#) (TIE ROD END)

6

7



**JOHN DEERE**  
Genuine Parts and Service