

REPLACEMENT PARTS GUIDE

2R Series Compact Utility tractors- 2038R

ENGINE



PRIMARY FUEL FILTER

[MIU800645](#)

SECONDARY FUEL FILTER

[MIU803127](#)

Replace after every 400 hours or annually, whichever occurs first.



OIL FILTER

[M806419](#)

Replace after every 400 hours or annually, whichever occurs first.

HYDRAULIC



OIL FILTER

[LVA14703](#)

Replace after every 400 hours or annually, whichever occurs first.



FILTER PACKS

[LVA23615](#) (2038R)

[M806419](#), [M131802](#), [LVA14703](#),
[MIU800645](#), [MIU803127](#), [LVA16054](#),
[M131803](#)

Each kit contains above filters, offering a complete solution for your maintenance needs to keep your tractor running at peak performance.

ENGINE



PRIMARY AIR FILTER

[M131802](#)

SECONDARY AIR FILTER

[M131803](#)

Replace after every 600 hours or as required



TRANSMISSION



OIL FILTER

[LVA16054](#)

Replace initially after 50 hours, then every 200 hours.

CAPACITIES

2R Series Compact Utility tractors- 2038R

CAPACITIES (Approximate):

Fuel Tank:

2038R.....32 L (8.5 gal)

Cooling System:

Cool-Gard™ II

.....4.9 L (1.3 gal)

2038R.....5.2 L (1.37 gal)

Crankcase with Filter:

Plus-50™

2038R.....4.3 L (1.13 gal)

Transmission and Hydraulic System:

Hy-Gard™

2038R.....23.5 L (6.2 gal)

Front Axle:

GL-5

2038R.....3.8 L (1 gal)

REPLACEMENT PARTS GUIDE

2R Series Compact Utility tractors- 2038R

CAB



SEAT
[TA14634](#) (SEAT ASSEMBLY)
[LVA22459](#)
[LVA22544](#) (OSF SEAT)

ENGINE



BATTERY
[TY26498](#) (DRY CHARGED BATTERY)
[TY27831B](#) (WET CHARGED BATTERY)




BRAKE DISK
[LVA19938](#) (DTA TRANSMISSION COMPONENTS)



ALTERNATOR
[LVA21236](#)



ENGINE



CLUTCH DISK
[SJ13448](#) (PTO)



BELT DRIVE
[LVU30203](#) (V-BELT) (LGTH = 995 mm)

AXLE



TIE ROD
[LVA15994](#) (TIE ROD ASSEMBLY)



CLICK PART NUMBER TO BUY
*See operator's manual for additional details.