

REPLACEMENT PARTS GUIDE

4075R Compact Utility Tractor

ENGINE

ENGINE OIL

[TY26668](#) (10W-30 PLUS-50™ II), (5.4 L (5.7 qt))
(CRANKCASE WITH FILTER)

Change Every 400 Hours or Annually, whichever comes first.



FUEL FILTER

[MIU803127](#)

Change after every 400 Hours/Annually.



AIR FILTER

[AP33330](#) (PRIMARY)

[AP33331](#) (SECONDARY)

Change every 600 Hours or Annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY6341](#)
[GREASE GUN](#)
[TY26183](#)

Change As Required.



OIL FILTER

[MIU800646](#)

Change Every 400 Hours or Annually, whichever comes first.



FUEL-WATER SEPARATOR

[MIA885324](#) (SEPARATOR)

[MIU802421](#) (FILTER ELEMENT)

Change after every 400 Hours or Annually.



DIESEL PARTICULATE FILTER

[MIU805113](#)



AXLE

FRONT AXLE OIL

[TY22000](#) (John Deere Low Viscosity Hy-Gard™) (8.0 L (8.5 qt))

Change every 600 Hours or Annually.



TRANSMISSION/ HYDRAULIC

HYDROSTATIC TRANSMISSION FILTER

[LVA10419](#)

Change after every 1200 hours or 3 years.



ELECTRICAL

KEY

[RE183935](#)



IGNITION SWITCH

[LVA21501](#)



LED FLOODLAMP

[RE593795](#) (12 V)



BATTERY

[TY26442B](#) (12 V)



LED HEADLIGHT

[TA26778](#) (12V)



FUEL & AIR

FILLER CAP

[AL213202](#)



CAB

AIR FILTER

[MIU10010](#) (FRESH AIR)

[MIU10011](#) (RECIRCULATION)

Change after every 50 Hours.



TRANSMISSION/ HYDRAULIC

TRANSMISSION OIL

[TY22000](#) (Low Viscosity Hy-Gard™) (J20D), (47.3 L (12.5 gal.))

Change Every 1200 hours or 3 Years.



OIL FILTER

[RE45864](#) (TRANSMISSION)

Change after every 1200 hours or 3 years.



V - BELT

[TR131487](#) (ALTERNATOR) (LGTH = 1090 mm, WIDTH = 13.4 mm, TK = 9.6 mm)

[LUV29375](#) (HVAC) (LGTH = 1508 mm, WIDTH = 13.4 mm, TK = 9.6 mm)

Change after every 400 Hours or Annually.

