




REPLACEMENT PARTS GUIDE


5025 Series - 5425(S.N.-002631), 5625(S.N.-001688) and 5725(S.N.-005047) Tractors


ENGINE

 **PRIMARY FUEL FILTER**
[RE522868](#)
[AL153517](#) (5625, 5725)

 **FINAL FUEL FILTER**
[RE60021](#)


 **PRIMARY AIR FILTER**
[KV16429](#)


 **SECONDARY AIR FILTER**
[AT171854](#)

 **OIL FILTER**
[RE59754](#) (DP052, DP053, DP054, TP059, TP062)
[RE504836](#) (DP055, DP057, DP058, DP060, DP061, TP065, TP066, TP068)




CAB

 **FRESH AIR FILTER**
[RE198488](#) (5625, 5725)

 **RECIRCULATION AIR FILTER**
[RE195491](#) (5625, 5725)
[R198887](#) (5625, 5725) (W/O A/C AIR FILTER)

HYDRAULIC FILTER

 **OIL FILTER**
[RE45864](#) (IOOS)
[RE197065](#)

Item	First 100 Hours	Every 250 Hours	Every 500 Hours	Every 1500hours / 2 Years
Engine Oil Filter	Replace	Replace		
Primary Air Filter element				Replace
Secondary Air Filter element				Replace
Primary Fuel Filter		Replace		
Secondary Fuel Filter		Replace		
Hydraulic/Transmission Oil Filter	Replace		Replace	

CAPACITIES

5025 Series - 5425(S.N.-002631), 5625(S.N.-001688) and 5725(S.N.-005047) Tractors

Machine Components	Part no.	Capacities (approx.)
Fuel Tank	RE246631	95 L (25 gal)
	RE280058 (5625,5725)	141.5 L (37.3 gal)
Engine Oil (John Deere Plus-50™ II)	PY10850 (8.5 L)	19.5 L (5.15 gal)
	PY10852 (6.5 L)	
	PYS10129 (4 L)	
Coolant (Cool-Gard™)	PY0746 (1 L)	20 L (5.28 gal)
	PY0747 (10 L)	
	PYS10130 (5 L)	
Transmission And Hydraulic Axle Oil (John Deere Hy-Gard™) SyncroPlus Transmission	PY0023 (20 L)	58 L (15.32 gal)
	PY0980 (5 L)	1 L (0.26 gal)
	PY0024 (1 L)	3 L (0.79 gal)
Mechanical Front Wheel Drive (MFWD) Axle Oil (APL/AS 2045) (APL/AS 2060) (Hy-Gard™)	PY0023 (20 L)	6.6 L (1.74 gal)
	PY0980 (5 L)	7 L (1.84 gal)
	PY0024 (1 L)	
Mechanical Front Wheel Drive (MFWD) Axle Oil (045JD) (045JDS20) (Hy-Gard™)	PY0023 (20 L)	9.5 L (2.5 gal)
	PY0980 (5 L)	10.6 L (2.8 gal)
	PY0024 (1 L)	
Mechanical Front Wheel Drive (MFWD) Hub oil (APL/AS 2060) (045JD) (045JDS20)	PY0980 (5 L)	1.7 L (0.44 gal) (7525)
	PY0024 (1 L)	2 L (0.5 gal) (7525)
		2 L (0.5 gal) (7525)

REPLACEMENT PARTS GUIDE

5025 Series - 5425(S.N.-002631), 5625(S.N.-001688) and 5725(S.N.-005047) Tractors

ENGINE



CLUTCH DISK
[SJ25811](#) (TRACTION)
[RE227648](#) (PTO)
[RE225677](#) (TRACTION)



BRAKE DISK
[RE45938](#)



ALTERNATOR
[AL166645](#) (90 A)



FAN DRIVE BELT
[L153280](#) (LGTH = 1910 mm)



BATTERY
[AL210285](#)



CAB



SEAT
[AP39778](#) (7420)(7520)

AXLE



TIE ROD
[AL116558](#) (LH)(7420)(7520)
[AL116559](#) (RH)(7420)(7520)
[AL80542](#) (AS2045)
[AL119215](#) (AS2060)
[AL110918](#)
[AL160111](#) (ASSEMBLY)
[AL160203](#) (745/750)
[AL68723](#) (7420)